



NÁVOD NA MONTÁŽ:

Kód: H0506(A,I,C)

- 1. Uvoľnite výfuk. ■ 2. Uvoľnite čalúnenie z podlahy v batožinovom priestore vozidla. ■ 3. Vyvrtajte 8ks otvorov $\varnothing 18\text{mm}$ do podlahy nad existujúcimi otvormi podľa obrázka. Ťažné zariadenie montujte po častiach podľa obrázka. Konzoly A a B upevnite skrutkami M10x100. Zľahka priskrutkujte rám C. ■ 4. Ťažné zariadenie vzhľadom na voľné uloženie ustavte do správnej polohy a všetky skrutkové spoje utiahnite momentom podľa tabuľky. ■ 5. Elektroinštaláciu zapojte podľa návodu. ■ 6. Skontrolujte správnosť pripojenia elektroinštalácie. ■ 7. Preveďte spätnú montáž demontovaných častí. ■ 8. Dotiahnite skrutkové spoje spojovacej gule (držíaka spojovacej gule) momentom podľa tabuľky.

FITTING INSTRUCTIONS:

- 1. Loosen the exhaust. ■ 2. Loosen the trim from the floor in the luggage compartment of the vehicle. ■ 3. Drill holes $\varnothing 18\text{mm}$ 8 pieces on the floor above the existing hole as shown. Install the tow-bar in parts as shown in the picture. Brackets A and B mounting screws M10x100. Gently screw the frame C. ■ 4. Put the tow-bar to an appropriate position with regard its clearance fit and torque the screw connections as shown in the table. ■ 5. Connect the electrical installation as described in the instructions for use. ■ 6. Make sure the electrical installation is properly connected. ■ 7. Reassemble any removed parts. ■ 8. Make sure the screws of the linkage ball (holder of the linkage ball) are tightened to the torque shown in the table.

DŔLEŽITÉ UPOZORNENIA:

- V miestach stykových plôch sa musí odstrániť pružná ochrana karosérie vozidla.
 - Vŕtané otvory treba ošetriť antikoróznou hmotou.
 - Použite len dodaný spojovací materiál v predpisanej triede kvality.
 - Elektrické zariadenie sa namontuje podľa podmienok prevádzky cestných vozidiel na pozemných komunikáciách.
 - Údaj S o maximálnom zvislom zaťažení na guľu je uvedený na výrobnom štítku ťažného zariadenia.
 - Na ťažnom zariadení nie je možné nič upravovať ani meniť.
 - Pred ukončením montáže je nutné prekontrolovať všetky spoje podľa tabuľky uťahovacích momentov!
 - V prípade akýchkoľvek nejasností je nutné obrátiť sa na výrobcu ťažného zariadenia.
 - Výrobca nenesie zodpovednosť za škody spôsobené nesprávnym použitím výrobku.
- #### IMPORTANT ATTENTIONS:
- Remove insulating material on a car body in grips and joints of a coupling device with a car body.
 - Put the anticorrosive substance on the drilled holes.
 - Use supplied mechanical strength jointing material.
 - Wiring of a coupling device must be up to a standard and car maker requirements.
 - Statement S about the maximum vertical ball downtake is printed on the tow bar label.
 - On the tow bar is no modification possible
 - Check all the joints, look in the table of the spining moments, before finishing the montage!
 - Contact the tow bar marker with any questions.
 - The manufacturer is not responsible for the damages caused by wrong using on the product.

Tabuľka uťahovacích momentov skrutkových spojov pevnosti 8.8 / Table of specified torque and hardenss settings 8.8

M6 - 9,5Nm, **M8** - 23Nm, **M10** - 46Nm, **M10x1,25** - 49Nm, **M12** - 79Nm, **M12x1,25** - 87Nm, **M12x1,5** - 83Nm, **M14** - 125Nm, **M16** - 195Nm