



ФАРКОПОВ

НÁVOD NA MONTÁŽ:

Kód: 00615(A,I,C)

- 1. Demontujte zadné svetlá. ■ 2. Demontujte zadný plastový nárazník a kovovú výstuhu nárazníka. ■ 3. Čažné zariadenie montuje po častiach podľa obrázka. Najprv k pozdĺžnym nosníkom priskrutkuje zlžka postranné konzoly A, B, C, D, na ktoror následne prichytíte rám E. Čažné zariadenie vzhľadom na volné uloženie ustawte do správnej polohy a všetky skrutkové spoje utiahnite momentom podľa tabuľky. ■ 4. Elektroinštaláciu zapojte podľa návodu.
- 5. Skontrolujte správnosť pripojenia elektroinštalácie. ■ 6. Demontujte spojovaciu guľu. ■ 7. Vyrežte vybranie v podhláde nárazníka pre držiak gule a elektrozasuvky podľa obrázka – DETAIL. ■ 8. Namontujte späť zadný plastový nárazník bez kovovej výstuhu, ktorý nahradza rám čažného zariadenia.
- 9. Prevedte spätnú montáž dalsích demontovaných častí. ■ 10. Namontujte spojovaciu guľu. Dotiahnite skrutkové spoje spojovacej gule (držiaka spojovacej gule) momentom podľa tabuľky.

FITTING INSTRUCTIONS:

- 1. Remove the rear lights. ■ 2. Remove the rear plastic bumper and the metal bumper reinforcement. ■ 3. Install the tow-bar in parts as shown in the picture. First, screw the A, B, C, D side consoles freely onto the longitudinal bars and then join the E frame to these consoles. Put the tow-bar to an appropriate position with regard its clearance fit and torque the screw connections as shown in the table. ■ 4. Connect the electrical installation as described in the instructions for use. ■ 5. Make sure the electrical installation is properly connected. ■ 6. Remove the linkage ball. ■ 7. Cut a cavity in the bumper bottom as shown in the picture – DETAIL. ■ 8. Replace the rear plastic bumper without the metal reinforcement, which will be replaced by the tow-bar frame. ■ 9. Reassemble any removed parts. ■ 10. Fit the linkage ball. Make sure the screws of the linkage ball (holder of the linkage ball) are tightened to the torque shown in the table.

ДОЛЕЖИТЕ УПОЗОРНЕНИЯ:

- V miestach stykových plôch sa musí odstrániť pružná ochrana karosérie vozidla.
- Vŕtané otvory treba ošetriť antikoróznom hmotou.
- Použite len dodaný spojovací materiál v predpisanej triede kvality.
- Elektrické zariadenie sa namontuje podľa podmienok prevádzky cestných vozidiel na pozemných komunikáciach.
- Údaj S o maximálnom zvislom zaťažení na guľu je uvedený na výrobnom štítku čažného zariadenia.
- Na čažnom zariadení nie je možné nič upravovať ani meniť.
- Pred ukončením montáže je nutné prekontrolovať všetky spoje podľa tabuľky utáhovacích momentov!
- V prípade akýchkoľvek nejasností je nutné obrátiť sa na výrobcu čažného zariadenia.
- Výrobca nenesie zodpovednosť za škody spôsobené nesprávnym použitím výrobku.

IMPORTANT ATTENTIONS:

- Remove insulating material on a car body in grips and joints of a coupling device with a car body.
- Put the anticorrosive substance on the drilled holes.
- Use supplied mechanical strength jointing material.
- Wiring of a coupling device must be up to a standard and car maker requirements.
- Statement S about the maximum vertical ball downtime is printed on the tow bar label.
- On the tow bar is no modification possible
- Check all the joints, look in the table of the spinning moments, before finishing the montage!
- Contact the tow bar marker with any questions.
- The manufacturer is not responsible for the damages caused by wrong using on the product.

Tabuľka utáhovacích momentov skrutkových spojov pevnosti 8.8 / Table of specified torque and hardenss settings 8.8

M6 - 9,5Nm, M8 - 23Nm, M10 - 46Nm, M10x1,25 - 49Nm, M12 - 79Nm, M12x1,25 - 87Nm, M12x1,5 - 83Nm, M14 - 125Nm, M16 - 195Nm